


A Caldwell Company



1 Remove the pulley
2 Use a chisel & hammer to
"dent" the shaft in 3-4 locations
PROTECT the other end of the
shaft to prevent deformation!
Denting the keyseat will prevent
the key from falling out too!

- 3. Install the pulley from the opposite end of the shaft
- 4. Secure rotation with key and setscrew.

The deformed shaft end will prevent the pulley/keyway from falling out

Universal Joint (no photo) P/N 20H03040



Use 1/2" x 1" x 7/16" Shaft Collar P/N 20H0361

	Securing Pulley With Inverted Shaft					
cdonovan	SIZE	FSCM NO		DWG NO		REV 1
2-9-2017	SCALE	1:1		SHEET	1 OF	1